


## MANUEL D'INSTRUCTION LED STREET LIGHT



Input Voltage:  
Ambiant Temperature:

AC 100-240 V, 50/60 Hz  
-25°C ~ 50°C



## **WARNING**

1. ENSURE ELECTRICITY IS SWITCHED OFF BEFORE INSTALL.
2. Please read through all following instructions before installing the unit.
3. User should prepare necessary accessories and spare parts (not provided) including junction box.
4. The raised lighting must be connected to the earth ground.
5. Install only by certified electrician.

Strictly follow these instructions for installing, avoid the intensity of power cable during installing.

## **INSTALLATION :**

